

RX MARINE INTERNATIONAL

Total Solution Total Protection

AN ISO CERTIFIED COMPANY



PHOSPHATE TEST KIT

Part/Order no:

RXSOL-62-5520

Directions for use:

- Take 2.5ml of water sample in the plastic test jar. Make it up to 25 ml mark with Distilled or Phosphate free raw water.
- Add 20 drops of Reagent Lp1, Mix Well by inverting at least 5 times.
- Add 5 drops of Reagent Lp2, Mix Well by inverting at least 5 minutes. Wait for 5 minutes.
- Rinse the 10 ml glass test jar with above solution & fill it up to 10 ml mark.
- Place the glass test jar on color card & match with different colors. (View from top side vertically downwards).
- Note down the ppm level of O-Phosphate as PO after 4 color comparison.

